



## VIRTUAL POLYMER COMPOUNDS, LLC

10478 Ridge Road • Medina, New York 14103

Phone: 585-735-9668 • Toll Free: 888-290-9522

Fax: 585-735-9965 • [www.virtualpolymercompounds.com](http://www.virtualpolymercompounds.com)

Administrative Office: One John James Audubon Pkwy • Amherst, NY 14228

# Enduro Shelter Installation Recommendations

**Enduro Shelters are provided with either an external or internal flange around the entire perimeter. These installation recommendations apply to both of these configurations when installing on a concrete pad. Project engineer's drawings and plans should be adhered to.**

- 1. Concrete pad should be level and a minimum of three inches thick over a gravel base, and be at least three inches larger than the Shelter on all sides.**
- 2. Position the Shelter in the center of the pad, or as instructed on the project engineers drawings. Sealant or caulk may be distributed between the pad and flange for a watertight seal.**
- 3. Drill a 3/8 inch hole through the center of the flange every 18 inches around the perimeter of the shelter. On smaller shelters center the holes on each side.**
- 4. Continue drilling into the concrete for another 3 inches with a masonry drill bit.**
- 5. Clean out the hole and insert a 3/8 inch stainless steel wedge anchor into the hole.**
- 6. With the nut and washer on the anchor, tap the anchor with a hammer until the washer rests on the top of the flange.**
- 7. Tighten the nut with a wrench approximately 3 to 4 turns.**
- 8. Repeat procedure for all the holes.**